

USER MANUAL • ELECTRIC VEHICLE

CABIN PLUS

Operation • Safety • Care



Motor	Electric motor
Edition	English • 1.0

Read in full before first use. Keep with the vehicle and pass it on with the vehicle.

01 / URBAN HOPPER

Vehicle & dealer

To be completed by the supplying dealer.

Model	Urban Hopper Cabin Plus
-------	-------------------------

Vehicle identification number (VIN)

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

Copy from the vehicle and check against the vehicle documents.

Handover date	Odometer

Dealer stamp / contact details

--

Dealer name / signature: _____

Have the fitted controls, parking restraint and charging equipment explained at handover. Keep the battery and charger instructions with this booklet.

Ask the dealer to clarify safety-related differences before use. Do not find out by trial and error.

Importer / responsible economic operator in the EU

STW GmbH · Adam-Opel-Str. 12
60386 Frankfurt am Main · Germany
info@stwtuning.de · +49 69 4089908-0

Contents

Chapter	Page
Vehicle & dealer	2
Use & safety	4
Checks before use	5
Vehicle and operation	6–10
Battery, charging and storage	11–13
Care, tyres and troubleshooting	14–16
In an emergency or accident	17
Transport and take-back	18
Inspection and service records	19
Service and reporting a problem	20

WARNING identifies a hazard that may cause serious injury or death. Follow the corresponding protective instruction.

02 / URBAN HOPPER

Use & safety

The Cabin Plus is an electric vehicle with handlebars, twist throttle and brake levers. Observe permitted seating and load limits in the actual vehicle documents.

Do not overload. Observe the permitted seating and load limits of the actual version. Carry people only on seats intended and approved for that purpose.

Safe operation

- Obtain instruction before first use and practise in a suitable area away from public traffic.
- Do not drive under the influence of alcohol or drugs, when tired or while affected by medication. Do not operate phones or multimedia while driving.

Eligibility and road use

Identify the approved version from the vehicle documents. Before using public roads, establish the required driving licence or certificate, minimum age, insurance and plates/registration. Observe local rules. Ask the dealer or relevant authority if uncertain. Instruction does not replace a required licence.

Protection and unauthorised use

Fasten any fitted seat belts. Wear firm footwear and clothing that does not obstruct the controls. Observe applicable helmet and seat-belt requirements.

The vehicle is not a toy. Children must not drive it or play with the vehicle, charger or keys. Secure it against unauthorised use.

03 / URBAN HOPPER

Checks before use

Inspect the entire vehicle before first use. Check the agreed delivery contents, visible transport damage and loose, missing or incompletely fitted parts.

Check before every drive

- Tyres and wheels: damage, loss of pressure and wear. Ask the dealer for the correct pressure if no clear specification is provided.
- Brakes, drive controls and steering: safe operation, free return and unobstructed movement. Keep the footwell clear.
- Check lights, indicators, brake lights, horn and displays.
- Adjust mirrors; check the seat, belts, doors and fitted latches. Secure luggage or cargo.
- Check battery charge and visible cables and connections. Fully disconnect the charger before driving.




WARNING

Do not drive if parts are damaged, safety-critical parts are missing, functions fail or safety is uncertain. Contact the dealer or a qualified workshop. Do not drive the vehicle to the inspection while its safety is uncertain.

We recommend inspection by a qualified workshop before first use. Have fasteners checked and, where necessary, tightened by a competent person to the manufacturer's specifications. Do not tighten indiscriminately.

User checks do not replace correct assembly or a pre-delivery inspection.

Instrument and start/stop button



Instrument display.

The instrument shows battery voltage, speed, indicators, charge, mileage and drive position. D = forward, N = neutral, R = reverse.




Start/stop button (1) and drive selector (2).

With the main switch on, the illuminated start/stop button enables readiness. The unlit position disables drive power. Have any remote-control function identified at handover.

04 / URBAN HOPPER

Left and right switch groups



Left switch group.


- Left: select main/dipped beam by symbol. Indicator ← left, → right, centre off. Press the horn button to sound.



Right switch group.

- Right: select low, medium or high speed setting. The light switch selects off, side/instrument lights or headlights added.
- The described wiper/cleaning button operates while held and stops when released.

Heating, cooling and windows



Comfort controls.

For cooling/heating, set airflow to 1, 2 or 3, press the centre button and select AC/PTC as appropriate. The instrument indicates the function.

An additional wiper switch turns the motor on in its marked position and off in the other. Use only the control actually fitted.

Window switch: the front marking raises the glass and the rear lowers it. Pull the interior handle to open. Operate locking with the labelled controls.



WARNING

Keep closing paths clear. Do not slam a locked door; unlock it first.

04 / URBAN HOPPER

Seat and main switch



Front seat and lock.

- Adjust the front seat with the rail lever and relock it afterwards. Do not drive if it fails to lock.
- The rear seat is fixed. Do not open electrical covers to carry out your own wiring work.
- The main switch is on the left of the front seat. Operate only the marked user controls explained at handover.

**WARNING**

Adjust the seat, backrest and mirrors only while stationary. Check that everything is securely locked after adjustment.

04 / URBAN HOPPER

Driving, braking and parking

- Complete pre-drive checks. Switch on the main switch and start/stop button. The display must be normal; resolve alarms before driving.
- Select direction and turn the throttle gently. Change direction only after stopping fully.
- Reduce throttle and progressively apply front and rear brake levers to slow down.

**WARNING**

Have the dealer demonstrate the fitted parking restraint before first use. Check that it holds securely while stationary. Do not drive without a clearly identified, functioning parking restraint.

Stop on firm, level ground, secure with the intended parking restraint, switch off drive readiness and take the key/remote.

05 / URBAN HOPPER

Battery & safe charging

Identify the battery and charger by their labels. Follow only the instructions for this combination. Do not charge if the match is unclear.

**WARNING**

Throughout charging, an instructed person must be awake, present and able to monitor the process. Do not charge while away or asleep.

- Use only the charger assigned to this vehicle and battery. A matching plug or nominal voltage alone is not sufficient.
- Inspect visible battery and charger parts, cables and plugs before charging. Do not use damaged, deformed or unusually hot components.
- Charge in a dry, well-ventilated place. Place the charger securely on a non-combustible surface; do not cover it. Keep children, combustible materials, sparks and flames away. Keep escape routes clear.

Observe the battery and charger temperature limits; ask the dealer first if these are missing. Do not charge frozen or potentially damaged batteries.

- Use a suitable, properly installed socket. Check the supply voltage against the charger's input rating.



Additional charging guide. It does not replace the correct charging instructions.

urbanminushopper.de/pages/elektrofahrzeug-laden

Using the charging equipment

For connection and completion of charging, follow the instructions for the battery actually installed and its assigned charger. These documents must clearly describe the charging combination in use.

Before charging

- Do not guess battery-selector positions, rearrange wiring or connect battery packs together. Operate any additional battery system only according to its corresponding instructions.
- Identify the connection order, charge indicator and completion signal from the charger instructions. Contact the dealer first if those instructions are missing or unclear.
- Park securely and switch off drive readiness and loads. Charge according to the charger instructions only after clear identification.



WARNING

Do not charge without clear charging instructions. Do not use a different battery or charger merely because it appears to fit.

Disconnect as specified by the charger instructions after correct completion. Keep away and respond safely if heat, smell or deformation occurs.

05 / URBAN HOPPER

Battery care & storage

Do not open, dismantle, modify or rewire the battery. Removal, replacement and work on internal connections require a competent professional. Never bypass protective circuits.

Storage charge level and recharging depend on the installed battery. Follow its accompanying instructions; do not apply charging or storage requirements for a different battery type. Contact the dealer before storage if information is missing.

Store dry and sheltered, secure against rolling and switch off loads. Clearly identify the battery and charging equipment before further use.

Returning to use

Clean and inspect the vehicle. Check tyres, brakes, steering, lights and latches, and check battery charge. After prolonged or uncertain storage, or if anything is abnormal, arrange professional inspection before charging or driving. Only test slowly in a suitable area once safety is established.

Care & professional checks

Cleaning

Switch off, remove the key and disconnect the charger. Clean surfaces with a soft, slightly damp cloth. Keep liquids out of electrical components. Do not use pressure or steam cleaning. Keep braking surfaces and tyres free of oil and grease.

Arrange regular professional checks

We recommend regular checks of the brakes, steering, running gear, wheels, structural parts, electrical cables and safety-critical fasteners by a qualified workshop. Agree inspection intervals according to use and condition; follow any model-specific requirements.



WARNING

Do not open the battery, charger, motor or controller or bypass safety functions. Safety-critical repairs and adjustments require competent personnel and the correct documentation.

After an accident, impact or safety-related abnormality, stop using the vehicle until it has been checked and faults rectified. Have work recorded.

Tyres, brakes & wear

Item	Model-source value
Front cold pressure	220 kPa (2.2 bar)
Rear cold pressure	250 kPa (2.5 bar)

- Check pressure only with cold tyres. Have damaged tyres, air leaks, cracks, embedded objects and deformed rims checked and repaired before driving again.
- Replace worn tyres in good time. Have the running gear and brakes checked for uneven wear, vibration or pulling to one side.
- Check braking performance and free return before every drive. Stop driving if stopping distances increase, fluid leaks or unusual noises occur; contact a workshop.
- Use only tyres, brake parts and spare parts suitable for the actual version. Do not guess fastener, brake-fluid or adjustment specifications.

Values from the corresponding model manual. Resolve any conflicting labels or equipment before use.

Troubleshooting safely

Carry out only the following external checks yourself. Stop driving if a safety-related fault occurs. Do not modify internal wiring, contacts or protective circuits.

Observation	Safe first step
Display remains off	Check the ignition/start control and intended user control of the main switch. If still off: contact service.
No drive	Secure the vehicle. Check the described start procedure, selected direction and release of the parking restraint. Do not force movement with the accelerator.
Low power or range	Check charge, load and tyre pressure. Charge only an undamaged, normal battery using the correct instructions.
Charging fault	Stop charging and disconnect only if safe. Inspect external cables and plugs. Contact service if damaged or the fault remains.
Sudden power loss	Stop safely. Do not repeatedly reset fuses or switches. Have the cause professionally investigated.



WARNING

Do not recreate brake, steering, drive-control or battery faults through risky test drives. Untrained users must not repair the charger or test the controller.

Report the model, fault description and, where available, VIN, mileage and photographs to the service team.

In an emergency or accident



WARNING

Keep away if there is smoke, fire or rapidly increasing heat. Warn others, leave the danger area and call the fire service on 112. State that an electric vehicle and its battery are involved.

- Do not inhale smoke or escaping gases. Do not touch, open or remove the battery.
- Do not move or transport a smoking, burning or very hot vehicle or battery yourself.
- Disconnect power only if you can do so without approaching the hazard or putting yourself at risk.
- After an accident, water ingress or visible damage, stop driving and do not recharge. Arrange professional inspection.

Report a safety problem

Also report non-urgent safety problems to the dealer or Urban Hopper service. Describe unusual heat, smell, smoke, rolling or brake and steering problems. The complaint form is not an emergency service.

Transport & take-back

Transporting the vehicle

Agree transport, loading and securing with the dealer or a suitable transport company beforehand. Do not drive to the workshop with a safety-related defect.

- Use suitable loading equipment and confirmed lifting/tie-down points. Do not lift or secure by mirrors, steering, body panels or the roof.
- No one may remain in the vehicle during transport. Secure loose parts and cargo.
- Do not independently send damaged batteries as ordinary parcels. Report the damage before transport or return.

Return batteries separately

Waste batteries must not be placed in household waste. The crossed-out wheeled bin means separate collection. Do not dismantle the battery. Contact the seller or Urban Hopper service for an appropriate return route.

Report damage, leakage or unusual heating in advance. Return the vehicle, battery and charger under the arrangements applicable to each.

09 / URBAN HOPPER

Inspection & service records

Have the dealer or workshop record inspections and work carried out.
Keep receipts and reports.

Date / km	Work / findings	Workshop / stamp

Next recommended inspection

Datum / Date: _____

km: _____

These entries record work carried out. Statutory rights remain unaffected.

Service and reporting a problem

A fault, transport damage or missing part? We will review your report through the form and discuss the next steps.



Scan the QR code or enter the address in your browser.

urbanminushopper.de/pages/reklamation

Describe the model and fault. The order number, VIN, mileage and photographs help identify the issue. You may also send photographs and documents by email.

You can report an issue without all documents and also by email or telephone. Discuss any return or collection in advance. In an emergency, call emergency services.

Statutory rights concerning defects

Your statutory rights concerning defects apply against your seller. This manual does not restrict those rights. Using the form is not a condition for exercising them.

About this manual

This manual has been prepared carefully and to the best of our knowledge using the available manufacturer and supplier documents, with editorial additions. Errors or unclear information may nevertheless occur. Please report them through the complaint form, by email or telephone, ideally stating the model, manual version and page.

Where safety-related information is unclear, do not use or charge the vehicle until clarified with the dealer or a qualified workshop. Statutory rights and liability remain unaffected.

Sales and service: G&C Handels GmbH & Co. KG
Josef-Bautz-Straße 26 · 63457 Hanau · Germany
info@urbanminushopper.de · +49 6181 36983-50